

# FR Arc Rainwear

## Sizing Charts

Jacket								
	S	M	L	XL	2X	3X	4X	5X
Chest	32-34	36-38	40-42	44-46	48-50	52-54	56-58	60-62
Sleeve Length	33	33	34	34	35	35	36	36
Center Length Back	32	32	32	32	32	32	32	32

If chest measurement falls between sizes, go up to the next largest size. Tall coat add 3" to sleeve length and 3" to center back.

Long Coat								
	S	M	L	XL	2X	3X	4X	5X
Chest	32-34	36-38	40-42	44-46	48-50	52-54	56-58	60-62
Sleeve Length	33	33	34	34	35	35	36	36
Center Length Back	48	48	48	48	48	48	48	48

If chest measurement falls between sizes, go up to the next largest size.

Pant								
	S	M	L	XL	2X	3X	4X	5X
Waist	28-30	32-34	36-38	40-42	44-46	48-50	52-54	56-58
Inseam - Regular	29	29	29	29	30	31	31	31
Inseam - Tall	32	32	32	32	33	35	35	35

Bib Overalls								
	S	M	L	XL	2X	3X	4X	5X
Waist	24-26	28-30	32-34	36-38	40-42	44-46	48-50	52-54
Inseam - Regular	29	29	29	29	29	30	31	31
Inseam - Tall	32	32	32	32	32	33	35	35

